



INSTALLATION INTO ENCLOSURE

- INSTRUCTIONS:**
1. COLLECT PARTS PER BOM.
 2. ADD LABELS AND HINDLE HEALTH LED LENSES AS SHOWN.
 3. ADD .GND WITH STARS AS PER CB0012-00 TYPE 13.
 4. ADD PART NUMBER SPECIFIC LATCH TO TOP DOOR LATCH POSITION.
 5. MOUNT AFTER APPLYING OVERLAY.

C:\Hindle Vault\Parts Directory\E - Assemblies\EI - Mechanical Assemblies\EI5167\EI5167-1X

REV. 2	DRN BY MS	CHK BY KB	APP BY ND	DATE 6/1/2023	DRN BY KB	DATE: 11/29/2021	HINDLEPOWER
DESCRIPTION CHANGED PART NO. FOR STANDARD DOOR OPTION. CHANGED DWG NO.					CHK BY MS	DATE: 12/1/2021	
PROPRIETARY AND CONFIDENTIAL NOTICE ANY REPRODUCTION, PARTIAL OR AS A WHOLE OF THIS DOCUMENT WITHOUT THE WRITTEN PERMISSION OF HINDLE POWER, INC IS STRICTLY PROHIBITED.					APP BY @:	DATE: 12/1/2021	TITLE ATEVO ASSY,FRNT.PNL,EV2/3,DOOR,5070 EVO 5070 FRONT DOOR ASSEMBLY
UNLESS OTHERWISE SPECIFIED ALL DIMENSIONS FOLLOW THE ANSI SYSTEM IPS (INCHES-POUNDS & SECONDS) TOLERANCES ARE: FRAC. ±1/64, DEC. ±0.015, ANG ±.25°							
						REV 2	SHEET 1 OF 1